



AGS INC

22442 S. Fey Drive – Frankfort, IL 60423
Ph: (708) 479-9458 – Fax: (708) 479-9478

Architectural Grilles & Sunshades, Inc.

AGS, Inc. Trellis Installation Instructions

1. Verify proper structure is installed per AGS, Inc. details
2. Install attachment brackets per AGS, Inc. shop drawings
 - Brackets must be installed level, plumb and square to the building
 - Brackets to be installed per AGS, Inc. centerlines on shop drawings
 - Stainless steel bolts are required – See shop drawings for size and quantity.
 - Use an isolator to separate dissimilar metals (steel from aluminum)

Start on one side of the building-

1. Install First Post V10 (eg- Level 4/ South End)
2. Install Both Channel Outriggers (C1 & C2) to V10 Post
3. Fasten (2) P2 Plates at splice location to Horizontal 6" x 6" tube T20
4. Then Install next post V9 with (2) P2 Plates
5. Install Both Channel Outriggers (C2 & C2) to V9 Post.
Continue this pattern per the tubes labeled on shop drawing.
6. Attach lower 3" x 6" Tubes to span the channel outriggers
7. Install Infill Units below - Check the size and verify you have the correct panel per letter tag on the shop drawings and hoist into position.